



KSI-2410

Monitor Mounting Instructions



Inside the Box

- KSI-2410 device
- Back bracket
- Back bracket thumbscrew
- 1 (large) double-sided 3M tape
- 1 (small) double-sided 3M tape
- Wet wipe

The KSI-2410 can be top- or bottom-mounted to the monitor. Preparation for each mounting option is different.


Prepare the Device for Monitor Mounting

- 1) Disassemble the 2410 by untightening the thumbscrew. Slide the back bracket off the 2410. Set the thumbscrew and bracket aside.
- 2) Measure either top or bottom monitor thickness, depending on whether you will top or bottom mount the 2410. If the monitor edge is curved or too thick, skip Steps 3, 6, 7 — the back bracket and smaller 3M tape piece will not be used.



Important: Use the enclosed wet wipe to free surfaces, where double-sided tape will be applied, of dust and dirt. Ensure tape application areas are dry before applying the tape.

- 3) Peel and apply the smaller 3M tape to the back bracket as shown. Either side of the back bracket is acceptable. Do not peel and expose the opposite adhesive side yet.
- 4) Cut the larger 3M tape piece to the same measurement as your monitor thickness.



- 5) Apply the cut 3M tape piece to the 2410 top if you are mounting the device to the bottom of the monitor. Do not peel and expose the adhesive side yet.

Apply the cut 3M tape piece to the 2410 bottom if you are mounting the device to the top of the monitor. Do not peel and expose the adhesive side yet.

Reassemble the Device for Mounting

Skip Steps 6 & 7 if your monitor thickness is too great or shaped in a way that causes the back bracket to impede taping the 2410 to monitor top or bottom.

- 6) Slide the back bracket onto the 2410 integrated bracket so that the two sections of 3M tape meet to form an angle.
- 7) Insert the thumbscrew into the hole and lightly hand tighten, in preparation for mounting, ensuring the back bracket is snug against the cut 3M tape.

Mount the Device

- 8) Peel and expose the adhesive side of the 3M tape piece(s).
- 9) Position and affix the device to the monitor according to your preferred mounting option, top or bottom.

Positioning the KSI-2410

The 2410 can be adjusted with the friction Dual-Hinge bracket to point the camera and PresenceLock™ toward the desktop user for optimal performance.

Reminder: The back bracket is not used for thick or irregularly-shaped monitor tops or bottoms. Instead, adhere using 3M tape only.



Scan to access the PresenceLock™ Programming Utility for Windows and iOS

The utility is used to adjust three basic functions.

- 1) Operating System (supports Windows, Mac, and Linux)
- 2) Zoning 1-5 (distance the PresenceLock™ will detect – 1 being shortest and 5 longest)
- 3) Time countdown from no person detected (5-60 seconds)



KSI Keyboards
14494 Wicks Boulevard
San Leandro, CA 94577
(510) 562-5000
info@ksikeyboards.com

